

Set Time and/or Date

- 1. Turn the control dial to Date/Time @\(\).
- Press the or button to adjust the hour.
- Press the button to advance to the next field.
- 4. Repeat steps 2 and 3 to set the current minutes, month, day and year.

Set Station Run Time Duration

- 1. Turn the control dial to Station Times .
- Press the (4) button to select the desired program to edit.
- Press the + or button to set the run time from 1–240 minutes.
- Press the button to select the next station.

5. Repeat steps 3 and 4 to set all stations as needed in the program. Note: Select - - - (dashes) to remove a station from the program.

Set Program Start Times

- Turn the control dial to Start Times (3).
- Press the (4) button to select the desired program to edit.
- Press the (+) or (-) button to set the desired start time. Select - (dashes) to remove.
- Press the button to select the next start time.
- 5. Repeat steps 3 and 4 to set another start time. Each program can have up to 3 start times.

Set Calendar Day Watering Schedule

- Press the (4) button to select the desired program to edit.
- Press the or button to select (ON) or (OFF). 4. Press the button to select the next day of the week.
- 5. Repeat steps 3 and 4 to set the remaining days of the week.

Set Interval Watering Schedule

- 1. Turn the control dial to Interval
- Press the (4) button to select the desired program to edit.
- Press the + or button to select the desired day interval (01-31). Note: Select - - - (dashes) to deactivate Day Interval.
- Press the button to advance to TODAY field.
- Press the or button to set the current day of the interval.

Set Odd or Even Watering Schedule

- Turn the control dial to Odd/Even.
- Press the (4) button to select the desired program to edit.
- Press the or button to select ODD, EVEN or - (dashes) to deactivate schedule.

Special Functions

- Turn the control dial to Special Special Functions.
- 2. Press the button to select the desired program to edit (if applicable).
- Press the button to select the desired special function (see below).
- Use the or button to modify the selection. 100% - Water Budget menu. Select between OFF and 200% in 10% increments.

HH:MM - Select the run time format between Hours:Minutes (HH:MM) or Minutes (MMM). ENG - Select the desired display language.

12H - Select either 12-hour or 24-hour time format.

CLR - Select the program(s) to clear/erase. Press the + button twice to clear.

XPY - Enable (Y) or Disable (N) the Accessory Port.

RS Y - Enable (Y) or Disable (N) the SENSOR terminals.

VX.XX - Displays the controller's firmware version.

Run Station Manually

- Turn the control dial to Manual Station.
- 2. Press the button to select the desired station to activate.
- Press the or button to set the run time duration.

Note: A single button press activates true manual ON which runs until midnight.

- 4. Repeat steps 2 and 3 to set additional stations.
- Return the control dial to Home.

Press the button to cancel watering, and again to resume normal operation.

Press to advance to next station.

Run Programs Manually

- Turn the control dial to Manual Programs.
- Press the button to select the desired program to run.
- Press the button to activate the selected program.
- 4. Repeat steps 2 and 3 to activate additional programs.
- Return the control dial to Home.

Press the button to cancel watering, and again to resume normal operation.

Press to advance to next station.

Watering Schedule Form		Program A	Program B	Program C	
Waterin	Weekly		SMTWTFS	SMTWTFS	
Day	Day Interv	al			
Schedu	Odd/Ever	1	□Odd □Even	□Odd □Even	□Odd □Even
Station	Location		Run Time	Run Time	Run Time
1					
2					
3					
4					
5					
6					
7					
8					
9					
Program Run Times 2 3					
		$\overline{}$			
		3			